

HOW MUCH DANCE FLOOR DO YOU NEED?*

* Assume that only one-third of your guests will dance, so the number of dancers shown in these graphs is only 33% of your total guests.

STARLIGHT II and CAM-LAM Dance Floor Panels 4 ft. x 4 ft. (122cm x 122cm)

FLOOR SIZE	NUMBER OF PANELS	NUMBER OF DANCERS	NUMBER OF CADDIES
8'x 8' (244cm x 244cm)	4	16	1
8'x12' (244cm x 366cm)	6	24	1
8'x16' (244cm x 488cm)	8	32	1
12'x16' (366cm x 488cm)	12	48	1
12'x20' (366cm x 610cm)	15	60	1
16'x16' (488cm x 488cm)	16	64	1
16'x20' (488cm x 610cm)	20	80	1
16'x24' (488cm x 732cm)	24	96	1
16'x28' (488cm x 853cm)	28	112	2
16'x32' (488cm x 975cm)	32	128	2
20'x20' (610cm x 610cm)	25	100	1
20'x24' (610cm x 732cm)	30	120	2
20'x28' (610cm x 853cm)	35	140	2
20'x32' (610cm x 975cm)	40	160	2
24'x32' (732cm x 975cm)	48	192	2
24'x36' (732cm x 1097cm)	54	216	3
28'x32' (853cm x 975cm)	56	224	3
32'x32' (975cm x 975cm)	64	256	3
32'x36' (975cm x 1097cm)	72	288	3
36'x36' (1097cm x 1097cm)	81	324	4
36'x40' (1097cm x 1219cm)	90	360	4
40'x40' (1219cm x 1219cm)	100	400	4